




LARDERA
COFFEE ROASTERS



CHESTNUT GRINDER

DESIGNED BY TIMEMORE

HOW TO GRIND



1

UNSCREW THE
BOTTOM PART




2

SELECT THE COARSENESS
SETTING



3

SCREW BACK THE BOTTOM
AND REMOVE LID



4

ADD COFFEE BEANS
UP TO 30 GRAMS



5

REPLACE LID AND
ROTATE THE HANDLE



6

UNSCREW BOTTOM TO
EMPTY GROUNDS

COARSENESS ADJUSTMENT



With the lid in place, turn dial clockwise for finer grinding. Turn counter-clockwise for coarser grinding.

To set desired grinder setting, rotate the dial clockwise until it stops. This will be your point of origin.

Rotate counter-clockwise from the point of origin to achieve a grind size that is best-suited for your method of coffee preparation:

ESPRESSO:	10-14 CLICKS
POUR OVER:	18-24 CLICKS
FRENCH PRESS:	25-27 CLICKS

DO NOT GRIND COFFEE AT THE FINEST 0-6 CLICKS SETTINGS AS THIS WILL DAMAGE THE BURRS AND SHORTEN THE USEFUL LIFE OF YOUR GRINDER.

WARNINGS



Use the grinder for coffee beans only.

Clean with dry brush only. Do not wash with water.

Burrs are sharp. Please exercise caution.

Keep out of reach of children.